



NOTES:

1. USE MEGALUG THRUST RESTRAINTS ON ALL FITTINGS.
2. SEE STANDARD PLATE 120 TO DETERMINE THE REQUIRED CONCRETE THRUST BLOCKING.
3. INSTALL POLY WRAP AROUND ALL PIPE AS DIRECTED BY THE ENGINEER.
4. ALL NUTS AND BOLTS TO BE COR-BLUE OR APPROVED EQUAL.
5. MAINTAIN A 2.0' (MIN.) CLEAR ZONE SEPARATION BETWEEN CONFLICTING UTILITIES.



CITY OF EDINA  
ENGINEERING  
& PUBLIC  
WORKS  
DEPTS.

OFFSET WATERMAIN

*Chad A. Miller*

APPROVED: CITY ENGINEER

REVISED:  
02-14

STANDARD  
PLATE  
125