

APPROVED

DATE

W/ PERMIT NUMBER

For office use only.

CITY OF EDINA

4801 50th Street West, Edina, MN 55424-1394
Building Inspections Department
(952) 826-0372 FAX (952) 826-0389 EdinaMN.gov



Ventilation, Makeup and Combustion Air Calculations Submittal Form for New Dwellings

These blank submittal forms and instructions are available on the City of Edina website. The completed form must be submitted at the time of application for a building and mechanical permit for new construction. Additional forms may be downloaded and printed [HERE](#).

Site Address		Date
Contractor	Completed By (please print)	Signature

Section A

Ventilation Quantity			
(Determine quantity by using Table R403.5.2 or Equation R403.5.2)			
Square feet (Conditioned area including Basement – finished or unfinished)		Total required ventilation	
Number of bedrooms		Continuous ventilation	

Directions - Determine the total and continuous ventilation rate by either using Table R403.5.2 or equation R403.5.2. The table and equation are below.

Table R403.5.2						
Total and Continuous Ventilation Rates (in cfm)						
	Number of Bedrooms					
	1	2	3	4	5	6
Conditioned space (in sq. ft.)	Total/ continuous	Total/ continuous	Total/ continuous	Total/ continuous	Total/ continuous	Total/ continuous
1000-1500	<input type="checkbox"/> 60/40	<input type="checkbox"/> 75/40	<input type="checkbox"/> 90/45	<input type="checkbox"/> 105/53	<input type="checkbox"/> 120/60	<input type="checkbox"/> 135/68
1501-2000	<input type="checkbox"/> 70/40	<input type="checkbox"/> 85/43	<input type="checkbox"/> 100/50	<input type="checkbox"/> 115/58	<input type="checkbox"/> 130/65	<input type="checkbox"/> 145/73
2001-2500	<input type="checkbox"/> 80/40	<input type="checkbox"/> 95/48	<input type="checkbox"/> 110/55	<input type="checkbox"/> 125/63	<input type="checkbox"/> 140/70	<input type="checkbox"/> 155/78
2501-3000	<input type="checkbox"/> 90/45	<input type="checkbox"/> 105/53	<input type="checkbox"/> 120/60	<input type="checkbox"/> 135/68	<input type="checkbox"/> 150/75	<input type="checkbox"/> 165/83
3001-3500	<input type="checkbox"/> 100/50	<input type="checkbox"/> 115/58	<input type="checkbox"/> 130/65	<input type="checkbox"/> 145/73	<input type="checkbox"/> 160/80	<input type="checkbox"/> 175/88
3501-4000	<input type="checkbox"/> 110/55	<input type="checkbox"/> 125/63	<input type="checkbox"/> 140/70	<input type="checkbox"/> 155/78	<input type="checkbox"/> 170/85	<input type="checkbox"/> 185/93
4001-4500	<input type="checkbox"/> 120/60	<input type="checkbox"/> 135/68	<input type="checkbox"/> 150/75	<input type="checkbox"/> 165/83	<input type="checkbox"/> 180/90	<input type="checkbox"/> 195/98
4501-5000	<input type="checkbox"/> 130/65	<input type="checkbox"/> 145/73	<input type="checkbox"/> 160/80	<input type="checkbox"/> 175/88	<input type="checkbox"/> 190/95	<input type="checkbox"/> 205/103
5001-5500	<input type="checkbox"/> 140/70	<input type="checkbox"/> 155/78	<input type="checkbox"/> 170/85	<input type="checkbox"/> 185/93	<input type="checkbox"/> 200/100	<input type="checkbox"/> 215/108
5501-6000	<input type="checkbox"/> 150/75	<input type="checkbox"/> 165/83	<input type="checkbox"/> 180/90	<input type="checkbox"/> 195/98	<input type="checkbox"/> 210/105	<input type="checkbox"/> 225/113

Equation R403.5.2

$$(0.02 \times \text{square feet of conditioned space}) + [15 \times (\text{number of bedrooms} + 1)] = \text{Total ventilation rate (cfm)}$$

Total ventilation – The mechanical ventilation system shall provide sufficient outdoor air to equal the total ventilation rate average, for each one-hour period according to the above table or equation. For heat recovery ventilators (HRV) and energy recovery ventilators (ERV) the average hourly ventilation capacity must be determined in consideration of any reduction of exhaust or out outdoor air intake, or both, for defrost or other equipment cycling.

Continuous ventilation - A minimum of 50 percent of the total ventilation rate, but not less than 40 cfm, shall be provided, on a continuous rate average for each one-hour period. The portion of the mechanical ventilation system intended to be continuous may have automatic cycling controls providing the average flow rate for each hour is met.

Section B

Ventilation Method		
Balanced, HRV (Heat Recovery Ventilator) or ERV (Energy Recovery Ventilator) – cfm of unit in low must not exceed continuous ventilation rating by more than 100%.	Low CFM	High CFM

Directions - Balanced ventilation systems are typically HRV or ERV's. Enter the low and high cfm amounts. Low cfm air flow must be equal to or greater than the required continuous ventilation rate and less than 100% greater than the continuous rate. (For instance, if the low cfm is 40 cfm, the ventilation fan must not exceed 80 cfm.) Automatic controls may allow the use of a larger fan that is operated a percentage of each hour.

Section C

Ventilation Fan Schedule			
Description	Location	Continuous	Intermittent

Directions - The ventilation fan schedule should describe what the fan is for, the location, cfm, and whether it is used for continuous or intermittent ventilation. The fan that is chose for continuous ventilation must be equal to or greater than the low cfm air rating and less than 100% greater than the continuous rate. (For instance, if the low cfm is 40 cfm, the continuous ventilation fan must not exceed 80 cfm.) Automatic controls may allow the use of a larger fan that is operated a percentage of each hour.

Section D

Ventilation Controls
(Describe operation and control of the continuous and intermittent ventilation)

Directions - Describe the operation of the ventilation system. There should be adequate detail for plan reviewers and inspectors to verify design and installation compliance. Related trades also need adequate detail for placement of controls and proper operation of the building ventilation. If exhaust fans are used for building ventilation, describe the operation and location of any controls, indicators and legends. If an ERV or HRV is to be installed, describe how it will be installed. If it will be connected and interfaced with the air handling equipment, please describe such connections as detailed in the manufactures' installation instructions. If the installation instructions require or recommend the equipment to be interlocked with the air handling equipment for proper operation, such interconnection shall be made and described.

Section E

Make-up air		
<input type="checkbox"/>	Passive (determined from calculations from Table 501.41)	
<input type="checkbox"/>	Powered (determined from calculations from Table 501.4.1)	
<input type="checkbox"/>	Interlocked with exhaust device (determined from calculation from Table 501.4.1)	
<input type="checkbox"/>	Other, describe:	
Location of duct or system ventilation make-up air: Determined from make-up air opening table		
	Cfm	Size and type (round, rectangular, flex or rigid)

(NR means not required)

Directions - In order to determine the makeup air, Table 501.4.1 must be filled out (see below). For most new installations, column A will be appropriate, however, if atmospherically vented appliances or solid fuel appliances are installed, use the appropriate column. **For existing dwellings, see IMC 501.4.3.** Please note, if the makeup air quantity is negative, no additional makeup air will be required for ventilation, if the value is positive refer to Table 501.3.2 and size the opening. Transfer the cfm, size of opening and type (round, rectangular, flex or rigid) to the last line of section D. The make-up air supply must be installed per IMC 501.4.2.3.

Table 501.4.1 PROCEDURE TO DETERMINE MAKEUP AIR QUANTITY FOR EXHAUST EQUIPMENT IN DWELLINGS (Additional combustion air will be required for combustion appliances, see KAIR method for calculations)				
	One or multiple power vent or direct vent appliances or no combustion appliances Column A	One or multiple fan-assisted appliances and power vent or direct vent appliances Column B	One atmospherically vent gas or oil appliance or one solid fuel appliance Column C	Multiple atmospherically vented gas or oil appliances or solid fuel appliances Column D
1. Use the appropriate column to estimate house infiltration				
a) pressure factor (cfm/sf)	0.15	0.09	0.06	0.03
b) conditioned floor area (sf) (including unfinished basements)				
Estimated House Infiltration (cfm): [1a x 1b]				
2. Exhaust Capacity				
a) continuous exhaust-only ventilation system (cfm); (not applicable to balanced ventilation systems such as HRV)				
b) clothes dryer (cfm)	135	135	135	135
c) 80% of largest exhaust rating (cfm); Kitchen hood typically (not applicable if recirculating system or if powered makeup air is electrically interlocked and match to exhaust)				
d) 80% of next largest exhaust rating (cfm); bath fan typically (not applicable if recirculating system or if powered makeup air is electrically interlocked and matched to exhaust)	Not Applicable			
Total Exhaust Capacity (cfm); [2a + 2b + 2c + 2d]				
3. Makeup Air Quantity (cfm)				
a) total exhaust capacity (from above)				
b) estimated house infiltration (from above)				
Makeup Air Quantity (cfm); [3a – 3b] (if value is negative, no makeup air is needed)				
4. For makeup Air Opening Sizing, refer to Table 501.4.2				

- A. Use this column if there are other than fan-assisted or atmospherically vented gas or oil appliance or if there are no combustion appliances. (Power vent and direct vent appliances may be used.)
- B. Use this column if there is one fan-assisted appliance per venting system. (Appliances other than atmospherically vented appliances may also be included.)
- C. Use this column if there is one atmospherically vented (other than fan-assisted) gas or oil appliance per venting system or one solid fuel appliance.
- D. Use this column if there are multiple atmospherically vented gas or oil appliances using a common vent or if there are atmospherically vented gas or oil appliances and solid fuel appliances.

**Makeup Air Opening Table for New and Existing Dwelling
Table 501.4.2**

	One or multiple power vent, direct vent appliances, or no combustion appliances Column A	One or multiple fan-assisted appliances and power vent or direct vent appliances Column B	One atmospherically vented gas or oil appliance or one solid fuel appliance Column C	Multiple atmospherically vented gas or oil appliances or solid fuel appliances Column D	Duct diameter
Passive opening	1 – 36	1 – 22	1 – 15	1 – 9	3
Passive opening	37 – 66	23 – 41	16 – 28	10 – 17	4
Passive opening	67 – 109	42 – 66	29 – 46	18 – 28	5
Passive opening	110 - 163	67 – 100	47 – 69	29 – 42	6
Passive opening	164 – 232	101 – 143	70 – 99	43 – 61	7
Passive opening	233 – 317	144 – 195	100 – 135	62 – 83	8
Passive opening w/motorized damper	318 – 419	196 – 258	136 – 179	84 – 110	9
Passive opening w/motorized damper	420 – 539	259 – 332	180 – 230	111 – 142	10
Passive opening w/motorized damper	540 – 679	333 – 419	231 – 290	143 – 179	11
Powered makeup air	>679	>419	>290	>179	NA

- Notes:
- A. An equivalent length of 100 feet of round smooth metal duct is assumed. Subtract 40 feet for the exterior hood and ten feet for each 90-degree elbow to determine the remaining length of straight duct allowable.
 - B. **If flexible duct is used, increase the duct diameter by one inch.** Flexible duct shall be stretched with minimal sags. Compressed duct shall not be accepted.
 - C. Barometric dampers are prohibited in passive makeup air openings when any atmospherically vented appliance is installed.
 - D. Powered makeup air shall be electrically interlocked with the largest exhaust system.

Section F

Combustion air			
Not required per mechanical code (No atmospheric or power vented appliances)			
Passive (see IFGC Appendix E, Worksheet E-1)	Size and type		
Other, describe:			

Explanation - If no atmospheric or power vented appliances are installed, check the appropriate box, not required. If a power vented or atmospherically vented appliance installed, use IFGC Appendix E, Worksheet E-1 (see below). Please enter size and type. Combustion air vent supplies must communicate with the appliance or appliances that require the combustion air.

Section F calculations follow on the next 2 pages.

IFGC Appendix E, Table E-1
Residential Combustion air (Required Interior Volume Based on Input Rating of Appliance)

Input Rating (Btu/hr)	Standard Method	Known Air Infiltration Rate (KAIR) Method (cu ft)			
		Fan Assisted or Power Vent		Natural Draft	
		1994 to present	Pre-1994	1994 to present	Pre-1994
5,000	250	375	188	525	263
10,000	500	750	375	1,050	525
15,000	750	1,125	563	1,575	788
20,000	1,000	1,500	750	2,100	1,050
25,000	1,250	1,875	938	2,625	1,313
30,000	1,500	2,250	1,125	3,150	1,575
35,000	1,750	2,625	1,313	3,675	1,838
40,000	2,000	3,000	1,500	4,200	2,100
45,000	2,250	3,375	1,688	4,725	2,363
50,000	2,500	3,750	1,675	5,250	2,625
55,000	2,750	4,125	2,063	5,775	2,888
60,000	3,000	4,500	2,250	6,300	3,150
65,000	3,250	4,875	2,438	6,825	3,413
70,000	3,500	5,250	2,625	7,350	3,675
75,000	3,750	5,625	2,813	7,875	3,938
80,000	4,000	6,000	3,000	8,400	4,200
85,000	4,250	6,375	3,188	8,925	4,463
90,000	4,500	6,750	3,375	9,450	4,725
95,000	4,750	7,125	3,563	9,975	4,988
100,000	5,000	7,500	3,750	10,500	5,250
105,000	5,250	7,875	3,938	11,025	5,513
110,000	5,500	8,250	4,125	11,550	5,775
115,000	5,750	8,625	4,313	12,075	6,038
120,000	6,000	9,000	4,500	12,600	6,300
125,000	6,250	9,375	4,688	13,125	6,563
130,000	6,500	9,750	4,875	13,650	6,825
135,000	6,750	10,125	5,063	14,175	7,088
140,000	7,000	10,500	5,250	14,700	7,350
145,000	7,250	10,875	5,438	15,225	7,613
150,000	7,500	11,250	5,625	15,750	7,875
155,000	7,750	11,625	5,813	16,275	8,138
160,000	8,000	12,000	6,000	16,800	8,400
165,000	8,250	12,375	6,188	17,325	8,663
170,000	8,500	12,750	6,375	17,850	8,925
175,000	8,750	13,125	6,563	18,375	9,188
180,000	9,000	13,500	6,750	18,900	9,450
185,000	9,250	13,875	6,938	19,425	9,713
190,000	9,500	14,250	7,125	19,950	9,975
195,000	9,750	14,625	7,313	20,475	10,238
200,000	10,000	15,000	7,500	21,000	10,500
205,000	10,250	15,375	7,688	21,525	10,783
210,000	10,500	15,750	7,875	22,050	11,025
215,000	10,750	16,125	8,063	22,575	11,288
220,000	11,000	16,500	8,250	23,100	11,550
225,000	11,250	16,875	8,438	23,625	11,813
230,000	11,500	17,250	8,625	24,150	12,075

1. The 1994 date refers to dwellings constructed under the 1994 Minnesota Energy Code. The default KAIR used in this section of the table is 0.20 ACH.
2. This section of the table is to be used for dwellings constructed prior to 1994. The default KAIR used in this section of the table is 0.40 ACH.